




## **UNDERCOUNTER DISHWASHER**

### **MODELS:**

MDB8959SBB1 (Black)  
MDB8959SBW1 (White)  
MDB8959SBS1 (Stainless)


# DOOR AND PANEL PARTS



# DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel	15		Handle
	W10532762	Installation Instructions		W10368715	Black		W10461636	Black
	W10555178	Energy Guide		W10368716	White		W10461635	White
	W10401491	Use & Care Guide	6	8534008	Screw, Set		W10324628	Stainless
	W10580509	Tech Sheet, English	7	W10315897	Insulation, Front Panel	16	W10350437	Insulation, Three Layer
	W10580510	Tech Sheet, French	8	W10288004	Nameplate	17	W10350242	Bracket, Control
2		Arm, Hinge	9	W10385107	Insulation, Toe Panel			
	8534854	Left Hand	10		Fastener			
	8534853	Right Hand		W10503548	Black			
3	W10321449	Barrier, Vapor Assembly		W10503549	White			
4		Panel Front (Include items 8, 13, 14)	11	304392	Screw			
	W10422050	Black	12	3400071	Screw			
	W10422053	White	13	W10316572	Screw			
	W10422054	Stainless	14	W10195726	Stud, Mounting			


# CONTROL PANEL AND LATCH PARTS



# CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Active Overlay & Insert)	3	W10539778	Control, Electronic	7	W10194937	Brace, Connector
	W10329535	Black	4	W10550100	Latch Assembly (Includes Switch)	8	W10401190	Box, Connector
	W10329534	White	5	W10195237	Clip. Control			
	W10329536	Stainless	6	W10348409	Screw			
2	W10401501	Jumper, Wire						


# INNER DOOR PARTS



# INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	6	W10304407	Dispenser, Assembly	10	W10177098	Screw
2	W10462232	Bracket, Dispenser	7	W10195007	Seal, Console/Door	11	W10524922	Cap, Rinse Aid
3	W10480715	Inner Door	8	8281217	Screw			
4	W10497235	Seal, Door Bottom	9	W10496098	Wiring Harness			
5	W10195837	Barrier, Vapor						

# FILL, DRAIN AND OVERFILL PARTS






# FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch	8	304392	Screw	16	W10292152	Miscellaneous Parts
2	8531412	Hose	9	370445	Clamp, Hose			Bag (Contains 2 Screws,
3	W10316375	Inlet, Water	10	W10481093	Drain Loop with Check	17	W10316376	2 Clamps, & 2 Brackets)
		(Also Order Items 4 &	11	W10195039	Switch, Overfill Control			Flapper
		17)	12	W10195035	Housing, Overfill			
4	8531323	Gasket	13	8531743	Gasket, Flat Assembly			
5	W10213825	Nut, Water Inlet	14	W10195038	Nut, Standpipe			
		(Also Order Item 4)	15	W10195036	Float & Retainer			
6	371505	Clamp, Hose			Assembly			
7	W10195047	Fill Valve Assembly						


# TUB AND FRAME PARTS



# TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10511187	Tub Assembly (Also Includes Heater Assembly)	11	3400074	Screw	24	W10300703	Bracket, Thermostat
2	W10275523	Shield, Side Tub	12	W10348411	Screw	25	W10339563	Thermostat
3	W10300924	Gasket, Tub	13	8268977	Wheel, Leg	26	W10300779	Strike, Latch
4	W10082838	Plug, Tub	14	W10304228	Leveler, Leg	27	3378128	Washer, Pronged Cup
5	8539404	Tie, Wire	15	8269145	Bracket, Undercounter	28	3400014	Screw, Grounding
6	W10179427	Seal, Cabinet	16	8270020	Spring, Door Balance	29	W10398392	Support Assembly, Rear
7	3400924	Retainer, Push In	17	3367670	Screw			
8	W10084086	Door Balance Assembly	18	3400892	Screw			
9	W10195368	Sound Insulation, Bottom	19	8268991	Cover, Terminal Box			
10		Tub Spacer	20	W10158291	Cable, Door			
	W10195630	Left Hand	21	304666	Retainer			
	W10195631	Right Hand	22	W10292870	Shield, Thermostat			
			23	8573239	Shield, Tub Sound			


# PUMP AND MOTOR PARTS



# PUMP AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8534952	Accumulator Assembly	10	3400217	Screw	18	W10239401	Motor
2	8283527	Shield, Motor	11	W10084567	Screen, Separation	19	8531017	Impeller Kit
3	W10348405	Screw	12	W10237169	Sump & Motor Assembly	20	W10134017	Indicator, Optical Wash
4	8572618	Sump with Seal	13	W10300599	Tab, Sump	21	W10334457	Capacitor
5	8268375	Check Valve, Sump Assembly	14	8533949	Nut	22	370445	Clamp, Hose
6	W10083957	Chopper Assembly	15	W10348269	Pump, Drain			
7	9741232	Screw	16	W10142656	Volute, Back (Also Order Item 19)			
8	8531857	Protector Inlet						
9	W10239404	Motor Assembly	17	8269144	Hose, Drain			


# UPPER WASH AND RINSE PARTS



# UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8559850	Feed Tube Assembly (Includes Item 3)	4	W10323424	Manifold	8	W10082841	Sprayarm, Upper
2	W10349488	Screw	5	W10082832	Hanger	9	W10082867	Mount
3	8557720	Sprayarm, Third Level	6	8268433	Seal, Sprayarm	10	W10118464	Fastener, Push-In
			7	W10082831	Probe, Manifold			

# HEATER PARTS






# HEATER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10329322	Heater Element Assembly (Includes Item 2)
2	717273	Washer, Rubber

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	8268548	Nut, Heater Element
4	3400931	Nut, Speed

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10343251	Shield, Heater Probe
NOTE: If heater element is removed, it must be replaced.		


# UPPER RACK AND TRACK PARTS



# UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10350382	Dishrack, Upper	7	8562029	Cupshelf Assembly	13	W10372814	Clip, Lite Item
2		Housing, Adjuster	8	W10267076	Clip, Dispenser Guard	14	W10482109	Basket, Utensil
	W10195372	Left Hand	9	W10250162	Cover, Adjuster	15	W10309090	Screw
	W10195373	Right Hand	10		Track, Assembly			
3	W10250160	Clip Adjuster		W10462359	Left Hand			
4	W10306646	Adjuster Assembly		W10462358	Right Hand			
5	W10195839	Strap, Tether Adjuster	11	W10158385	Clip, Stemware			
6	W10195840	Position, Adjuster	12	8562026	Clip, Cupshelf			


# LOWER RACK PARTS



# LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525646	Dishrack, Lower	5	W10199681	Lid, Silverware Basket	7	W10175279	Retainer, Tine Row
2	W10512377	Cupshelf	6	W10056272	Tine Row, Fold Down	8	W10082850	Basket, Utensil Row
3	W10195416	Wheel & Transport Assembly						
4	W10199701	Silverware, Basket Assembly						

# LOWER WASHARM PARTS



# LOWER WASHARM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10330588	Wash Arm Assembly	3	8268340	Bearing, Lower Sprayarm
2	8268343	Cap, Internal Rear Feed	4	W10077898	Hub, Lower Sprayarm

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Kit
		DRAIN HOSE
	3385556	12 Ft.

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

## PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White
	4392900	Biscuit/Bisque

## POWER CORD KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

## ANTI-TIP KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

## DISHRACK REPAIR

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Gray
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis